

PATENT NO: 2014100825

ENDURAPANEL® INSTALLATION INSTRUCTIONS

STEPS:

- Plan layout before starting.
- End joints must be staggered unless on a stud or joist.
- Ensure all cuts are fully coated with Endurapanel® coloured primer.

Apply Endurapanel® coloured primer

- liberally to cut edge, wiping off excess with a rag.

Ensure that external applications are

- secured with a galvanized or stainless steel fixings.

Fixings at 600 centres.

- If Endurapanel® is installed on a wall with the grooves running vertically, the panels must not be installed at an angle greater than 15 degrees from vertical.

Endurapanel® that is installed on a wall

- with the grooves running horizontally, must be installed at 90 degrees, (i.e a vertical wall).

