INSTALLATION GUIDELINES






Im	dex	1	Ariaply installation - Frame work
Im	dex	2	Mounting method
lm	dex	3	General mounting instructions
In	dex	4	Surface preparation



Ariaply installed with 10mm shadow line:


- Minimum of 90mm framework behind joins
- Additional frame work to be minimum of 35mm at NO MORE than 600mm intervals.
- When applying pressure to frame work, ensure it has minimal to no deflexion
- Clean frame work and rear of Ariaply, please refer to index 4
- Apply black pressure sensitive vinyl tape or black paint to shadow line areas,
- ENSURE TAPE OR PAINT DOES NOT COME IN CONTACT WITH THE BONDING AREA
- Apply X-Tack adhesive as illustrated below and in general mounting instruction
- DO NOT join adhesive beads, leave a gap of 30mm
- Bond Ariaply to adhesive pressing firmly over adhesive beads, please refer to index 2 mounting method



When adhering Ariaply to newly installed frame work, apply adhesive to frame work not Ariaply, to ensure adhesive is placed in the correct location When applying shadow line vinyl backing tape or black paint to frame work, ENSURE IT DOES NOT come in contact with the bonding areas


Ariaply installed with butt joins:

- Minimum of 70mm frame work behind joins
- Additional frame work to be minimum of 35mm at NO MORE than 600mm intervals.
- When applying pressure to frame work, ensure it has minimal to no deflexion
- Clean frame work and rear of Ariaply, please refer to index 4
- Apply X-Tack adhesive as illustrated below and in general mounting instruction
- DO NOT join adhesive beads, leave a gap of 30mm
- Bond Ariaply to adhesive pressing firmly over adhesive beads, please refer to index 2 mounting method



Installation of 9mm and 12.5mm Ariaply to ceiling frame work:


- Ensure frame work is solid and suitable for installation of Ariaply, with minimal to no deflexion
- Clean frame work and rear of Ariaply, please refer to index 4
- Apply X-Tack adhesive to frame work with internal beads at NO MORE than 600mm intervals. See illustration and general mounting instructions
- DO NOT join adhesive beads, leave a gap of 30mm See illustration below



Installation of 6mm - 19mm Ariaply to wall frame work:

- Ensure frame work is solid and suitable for installation of Ariaply, with minimal to no deflexion
- Clean frame work and rear of Ariaply, please refer to index 4
- Apply X-Tack adhesive to frame work at NO MORE than 600mm intervals
- and 150mm flushing beads See illustration and general mounting instructions - Bond Ariaply to frame work pressing firmly over adhesive beads,
- please refer to index 2 mounting method





ADHESIVE BEAD

ADHESIVE BEAD

1

600mm

Mounting method Index



1- position panel in place (minor adjusments up to 5mm are possible in the first 5 minutes) 2- press Ariaply firmly over adhesive beads

Be sure to have surfaces bonded within five minutes from commencing X-Tack application Once the panel has been pushed firmly into position, the optimum thickness for X-Tack is 1.5mm - 3mm .

General mounting instructions Index

DO NOT CUT OFF X-TACK NOZZLE


Hold cartridge gun with X-Tack tube at 90° to the surface. Ensure "V" shape cutout in nozzle is facing away from the direction you are moving the tube, leaving behind a 10mm TRIANGULAR shaped bead.

When applying X-Tack using the shadow line method, ensure sufficiant clearance so X-Tack adhesive bead DOES NOT come in contact with vinyl backing tape or painted area.

Be sure to have all surfaces bonded within five minutes. Bead width should be approximately 10mm. Press Ariaply firmly where beads have been applied. Once the panel has been pushed in position, the optimum thickness for X-Tack is 1.5mm - 3mm.

TO ENSURE CORRECT AMOUNT OF ADHESIVE AND SMOOTH APPLICATION TEC7 CARTRIDGE GUNS OR ELECTRIC CAULKING GUNS ARE ESSENTIAL.

Application temperature range is 5°c to 40°c



Surface preparation Index /1

To achieve the perfect bond, surface preparation with Tec7 cleaners is essential.

For preparation of metal and non-porous frame work

Tec7 Cleaner:

- Ideal surface preparation for Tec7 products on:
- galvanised steel, stainless steel, mild steel, aluminium and most non-porous frame work
- Removes uncured X-Tack and Tec7 adhesives
- Test on inconspicuous area for colour fastness

Use: Spray Tec7 Cleaner on the frame work to which the Ariaply is to be bonded, allow cleaner to take effect, approximately 10 seconds, rub dry with a microfibre cloth or paper towel. Allow Tec7 Cleaner to evaporate completely prior to bonding. If necessary, repeat the process.

For preparation of timber frame work

Ensure timber frame work is clean, dust free and clear of any contaminants



For preparation of Ariaply

Multiclean:

- Ideal surface preparation for Tec7 products on Ariaply
- Test on inconspicuous area for colour fastness



Use: Shake can well, apply to rear of the Ariaply and leave to take effect for approximately 10 seconds, rub dry with a microfibre cloth or paper towel. Allow Multiclean to evaporate completely prior to bonding. If necessary, repeat the process.







